Thermal overload relays - 3UA / 3UC

Relays for heavy starting applications, independent mounting

Bimetal relay	Current type of mounting	Current setting range A	Туре
3UA50	Contactor [®] mounting (3TF30/31)	0.1 - 0.16 0.16 - 0.25 0.25 - 0.4 0.4 - 0.63 0.63 - 1 0.8 - 1.25 1 - 1.6 1.25 - 2	3UA5000-0A 3UA5000-0C 3UA5000-0G 3UA5000-0G 3UA5000-0J 3UA5000-0K 3UA5000-1A 3UA5000-1B
		1.6 - 2.5 2 - 3.2 2.5 - 4 3.2 - 5 4 - 6.3 5 - 8	3UA5000-1C 3UA5000-1D 3UA5000-1E 3UA5000-1F 3UA5000-1G 3UA5000-1H
		6.3 - 10 8 - 12.5 10 - 14.5	3UA5000-1J3UA5000-1K3UA5000-2S
3UA52	Contactor [®] mounting (3TF32/33)	1 - 1.6 1.25 - 2 1.6 - 2.5 2 - 3.2 2.5 - 4 3.2 - 5	3UA5200-1A 3UA5200-1B 3UA5200-1C 3UA5200-1D 3UA5200-1E 3UA5200-1F
		4 - 6.3 5 - 8 6.3 - 10 8 - 12.5	3UA5200-1G3UA5200-1H3UA5200-1J3UA5200-1K
		10 - 16 12.5 - 20 16 - 25	3UA5200-2A3UA5200-2B3UA5200-2C
3UA55	Contactor [®] mounting (3TF34/35, 44/45)	10 - 16 12.5 - 20 16 - 25 20 - 32	3UA5500-2A3UA5500-2B3UA5500-2C3UA5500-2D
		25 - 36 32 - 40 36 - 45	■ 3UA5500-2Q ■ 3UA5500-2R ■ 3UA5500-8M

	11,13,	32 36	- 40 - 45	■ 3UA5500-2R ■ 3UA5500-8M
Bimetal relay	Current type of mounting	Current setting range A		Туре
3UA58-Z1	Contactor® mounting (3TF46, 3TF47, 3TF48, 3TF49)	16 20 25	- 25 - 32 - 40	3UA5800-2CZ1 3UA5800-2DZ1 3UA5800-2EZ1
		32 40	- 50 - 57	3UA5800-2FZ13UA5800-2TZ1
		50 57 63 70	- 63 - 70 - 80 - 95	3UA5800-2PZ13UA5800-2VZ13UA5800-2UZ13UA5800-8YZ1
3UA58-Z2	Contactor [®] mounting (3TF47 7)	16 20 25	- 25 - 32 - 40	3UA5800-2CZ2 3UA5800-2DZ2 3UA5800-2EZ2
		32 40	- 50 - 57	3UA5800-2FZ23UA5800-2TZ2
		50 57 63	- 63 - 70 - 80	3UA5800-2PZ23UA5800-2VZ23UA5800-2UZ2
3UA58 30	Contactor [®] mounting (3TF50)	70	- 95	■ 3UA5830-5B
		85 95	- 105 - 120	■ 3UA5830-5C ■ 3UA5830-5D
3UA62	Independent mounting	85 115	- 135 - 180	■ 3UA6230-5A ■ 3UA6230-5B
		160	- 250	■ 3UA6230-5C
		200 250	- 320 - 400	■ 3UA6230-5D ■ 3UA6230-5E
3UA68		320 400	- 500 - 630	3UA6830-5F 3UA6830-5G


@	Can be converted	to independent	mounting	using accessory	

Current setting range A	Туре	Unit LP ₹	Current setting range A	Туре	Std. pkg. (nos.)
2.5 - 4	3UC5030-5E		40 - 63	3UC5830-5G	1
4 – 6.3	3UC5030-5G		63 - 100	3UC6230-5J	1
6.3 – 10	3UC5030-5J		100 – 160	3UC6230-53	
8 –12.5	3UC5030-5K	20985			!
10 –16	3UC5830-5A		125 – 200	3UC6630-5B	1
16 – 25	3UC5830-5C		160 – 250	3UC6630-5C	1
25 –40	3UC5830-5E		250 – 400	3UC6630-5E	1

Note: Relays always supplied in manual execution, can be converted at site to auto execution.

Accessories for 3UA birelays

Description	For relay type	Туре	Std. pkg. (nos.)
Accessory for independent mounting	3UA50 3UA52 3UA55 3UA58 3UA58 30	3UX14183UX14203UX14253UX14213UX1421-0XA	1 1 1 1
Resetting plunger funnel	3UA5/6, 3UC5/6	3UX1011 3UX1013	10 10
Reset cord + holder: 400 mm length 600 mm length	3UA5/6, 3UC5/6	3UX1015 3UX1016	5 5
Protection cover	3UA58/3UA58 30 Other 3UA5/6	3UX11101YA 3UX11111YA	10 10
3UA5800-2. or 3UA58 3UA5800-2.Z1 or 3UA	Set of 3 terminals to convert from 3UA5800-2. or 3UA5800-2.Z2 to 3UA5800-2.Z1 3UA5800-2.Z1 or 3UA5800-2.Z2 to 3UA5800-2. 3UA5800-2. or 3UA5800-2.Z1 to 3UA5800-2.Z2		10 10 10



Stock items